

Technical Update



Setting the Turn-on Volume for the ASAP3D SE Local (B) input

Firmware Revision V11 applies to units starting with serial number 0924460930XXXXX and later. Older units are NOT field-upgradeable.

The ASAP3D SE now offers a new volume preset feature which allows the Local (B) input to turn on at a specific volume. This additional feature applies only when the unit is set for IR Control. Previously, the local turn-on volume was always set to zero. The user would then have to ramp-up the volume to a desired level.

The volume preset feature only applies to the local (B) input and requires the IR trigger switch to be selected to the (ON) position.

To set the Local source turn-on volume:

1. Trigger the amplifier so it switches to the Local source input by using Audio + IR, Voltage + IR, AC + IR or IR triggering.
2. With a keypad or through an IR receiver, use IR volume jump or step-up commands to bring the volume to the desired turn-on level.
3. Press-and-hold the front-panel STBY button for five seconds. The House LED will blink twice to signal that the turn-on volume level has been stored.
4. Any time the amplifier is triggered to the Local Source Input, the volume will start at the volume level now programmed into the memory.

To set the volume level back to factory default:

1. Unplug the amplifier's power cord from the back of the amplifier or wall outlet.
2. Press-and-hold the front-panel AC SENSE button while plugging-in the power cord.